



Altomed Ltd  
2 Witney Way,  
Baldon Business Park,  
Tyne & Wear,  
NE35 9PE,  
England.  
Comments, queries or orders  
please contact:  
Tel: +44 (0)191 519 0111  
Fax: +44 (0)191 519 0283  
E-mail: admin@altomed.com



#### The **Altomed Silicone and PMMA (Lucite)**

**Conformers** are used to help retain the socket in post enucleation and eversion cases.

The **PMMA Symblepheron Rings** are used if there is excessive swelling or if the patient lacks volume in the socket post enucleation or eversion.

- Silicone - Soft and flexible
- PMMA - Hard and transparent

**To insert** - Very carefully pull the upper eye lid up, gently place the conformer in the socket and then pull the lower lid over the device. Use a suitable ophthalmic lubricant if required.

**To remove** - Very carefully pull the lower lid out and gently slide the conformer out.

Form ALT I035 Issue 05/0313

If the patient feels the conformer has become contaminated and it is not as comfortable as normal, eg it feels gritty etc, it is recommended to replace the device with a new one.

Cleaning the device at home may result in further degradation of quality through the use of unsuitable chemicals or by coming into contact with contaminated fingers, solutions, substances or surfaces.

#### Approximate dimensions:

**Conformers:** 20mm x 23mm for Small Size  
21mm x 25mm for Medium Size  
25mm x 28mm for Large Size

**Rings:** 20mm x 23mm for Small Size  
21mm x 25mm for Medium Size  
25mm x 28mm for Large Size



Altomed Ltd  
2 Witney Way,  
Baldon Business Park,  
Tyne & Wear,  
NE35 9PE,  
England.  
Comments, queries or orders  
please contact:  
Tel: +44 (0)191 519 0111  
Fax: +44 (0)191 519 0283  
E-mail: admin@altomed.com



#### The **Altomed Silicone and PMMA (Lucite)**

**Conformers** are used to help retain the socket in post enucleation and eversion cases.

The **PMMA Symblepheron Rings** are used if there is excessive swelling or if the patient lacks volume in the socket post enucleation or eversion.

- Silicone - Soft and flexible
- PMMA - Hard and transparent

**To insert** - Very carefully pull the upper eye lid up, gently place the conformer in the socket and then pull the lower lid over the device. Use a suitable ophthalmic lubricant if required.

**To remove** - Very carefully pull the lower lid out and gently slide the conformer out.

Form ALT I035 Issue 05/0313

If the patient feels the conformer has become contaminated and it is not as comfortable as normal, eg it feels gritty etc, it is recommended to replace the device with a new one.

Cleaning the device at home may result in further degradation of quality through the use of unsuitable chemicals or by coming into contact with contaminated fingers, solutions, substances or surfaces.

#### Approximate dimensions:

**Conformers:** 20mm x 23mm for Small Size  
21mm x 25mm for Medium Size  
25mm x 28mm for Large Size

**Rings:** 20mm x 23mm for Small Size  
21mm x 25mm for Medium Size  
25mm x 28mm for Large Size



Altomed Ltd  
2 Witney Way,  
Baldon Business Park,  
Tyne & Wear,  
NE35 9PE,  
England.  
Comments, queries or orders  
please contact:  
Tel: +44 (0)191 519 0111  
Fax: +44 (0)191 519 0283  
E-mail: admin@altomed.com



#### The **Altomed Silicone and PMMA (Lucite)**

**Conformers** are used to help retain the socket in post enucleation and eversion cases.

The **PMMA Symblepheron Rings** are used if there is excessive swelling or if the patient lacks volume in the socket post enucleation or eversion.

- Silicone - Soft and flexible
- PMMA - Hard and transparent

**To insert** - Very carefully pull the upper eye lid up, gently place the conformer in the socket and then pull the lower lid over the device. Use a suitable ophthalmic lubricant if required.

**To remove** - Very carefully pull the lower lid out and gently slide the conformer out.

Form ALT I035 Issue 05/0313

If the patient feels the conformer has become contaminated and it is not as comfortable as normal, eg it feels gritty etc, it is recommended to replace the device with a new one.

Cleaning the device at home may result in further degradation of quality through the use of unsuitable chemicals or by coming into contact with contaminated fingers, solutions, substances or surfaces.

#### Approximate dimensions:

**Conformers:** 20mm x 23mm for Small Size  
21mm x 25mm for Medium Size  
25mm x 28mm for Large Size

**Rings:** 20mm x 23mm for Small Size  
21mm x 25mm for Medium Size  
25mm x 28mm for Large Size



Altomed Ltd  
2 Witney Way,  
Baldon Business Park,  
Tyne & Wear,  
NE35 9PE,  
England.  
Comments, queries or orders  
please contact:  
Tel: +44 (0)191 519 0111  
Fax: +44 (0)191 519 0283  
E-mail: admin@altomed.com



#### The **Altomed Silicone and PMMA (Lucite)**

**Conformers** are used to help retain the socket in post enucleation and eversion cases.

The **PMMA Symblepheron Rings** are used if there is excessive swelling or if the patient lacks volume in the socket post enucleation or eversion.

- Silicone - Soft and flexible
- PMMA - Hard and transparent

**To insert** - Very carefully pull the upper eye lid up, gently place the conformer in the socket and then pull the lower lid over the device. Use a suitable ophthalmic lubricant if required.

**To remove** - Very carefully pull the lower lid out and gently slide the conformer out.

Form ALT I035 Issue 05/0313

If the patient feels the conformer has become contaminated and it is not as comfortable as normal, eg it feels gritty etc, it is recommended to replace the device with a new one.

Cleaning the device at home may result in further degradation of quality through the use of unsuitable chemicals or by coming into contact with contaminated fingers, solutions, substances or surfaces.

#### Approximate dimensions:

**Conformers:** 20mm x 23mm for Small Size  
21mm x 25mm for Medium Size  
25mm x 28mm for Large Size

**Rings:** 20mm x 23mm for Small Size  
21mm x 25mm for Medium Size  
25mm x 28mm for Large Size